General information			
Type of data	Emissions testing		
Place of experimentation	Delhi (India)		
Dates of the experiments	2018		
	<u>Feedstock</u>		
Type of faecal material	Fresh faecal waste		
Location of collection	Coimbatore, India		
Age before collection	1-3 days		
Moisture content	N/A		
Total solids content	N/A		
Volatile solids content	N/A		
Ash content	N/A		
Presence of trash?	No		
Pre-treatment	N/A		
	Experimental Procedure		
Drying experimental setup	A custom-designed dryer connected to an exhaust system		
Holding or residence time	8 hours		
Operating conditions	80°C		
Sample form in the dryer	Sample produced by a jerky gun		
Analysed parameters	ISO 30500 air stack parameters		
Employed method	Gas analysis through the ISO 30500 sampling trains Sampling from exhaust pipe and work zone: a nozzle, followed by a thimble filter, sampling probe, sampling kit containing gas specific absorbing solutions for SO ₂ , H ₂ S, NH ₃ , VOC, PAH, and gas meter measuring CO, CO ₂ , NOx, and O ₂ , exit via vacuum pump. PM _{2.5} : cyclonic setup containing a nozzle at one end, connected to a probe at the other end; a 40 mm glass fibre		

Gas analysis Addendum of data

filter to collect particles smaller than 2.5 micron in diameter, then weighed to determine PM2.5 particles in the exhaust air

Publications

_

Data source files

https://www.dropbox.com/s/xq4lwro9hciv40v/Gas%20emissions%20testing_TUV%20Noida_India %20%282018%29.xlsx?dl=0

Additional Notes

- Tests performed to validate testing methods of the ISO 30500 standard
- O During first 4 days of drying, gas emissions measured from a sampling port in the exhaust pipeline (photo A).
- During 5th day of operation, gas emissions measured near the exhaust hood of the dryer (photo B).
- 2 drying processes per day.

Α



В



Description of Data

Gas emissions from sampling in the exhaust pipeline (n=8)

Parameter	со	NO _X : NO+NO ₂	H₂S	VOC (benzene)
Stack Results (mg/Nm³)	BDL (DL:1.0)	BDL (DL:1.0)	BDL (DL:0.1)	BDL (DL:0.5)
Standard Deviation (mg/Nm³)	BDL (DL:1.0)	BDL (DL:1.0)	BDL (DL:0.1)	BDL (DL:0.5)

- Lower concentration of the compounds measured from the pipe line (probable because dilution with air)
- Compounds detected during drying: CO, NO_x, SO₂, NH₃, particles PM_{2.5}

Parameter	SO₂	PM _{2.5}	NH ₃	РАН
Stack Results (mg/Nm³)	10	BDL (DL:1.0)	BDL (DL:0.1)	BDL (DL:0.0001)
Standard Deviation (mg/Nm³)	5.9	BDL (DL:1.0)	BDL (DL:0.1)	BDL (DL:0.0001)

^{*}BDL: below detectable limit

Gas emissions from sampling near the exhaust hood (n=2)

Parameter	со	NO _X (NO+NO ₂)	H₂S	voc
Average (mg/m³)	1.145	14.1	BDL (DL:0.1)	BDL (DL:0.5)
S.D. (mg/m³)	0.810	3.960	BDL (DL:0.1)	BDL (DL:0.5)
Range (LL –HL) mg/m3	0.335 – 0.955	10.14 – 18.06	BDL (DL:0.1)	BDL (DL:0.5)

Parameter	SO₂	PM _{2.5}	NH₃	РАН
Average (mg/m³)	2.85	16.5	0.0031	BDL(DL:0.0001)
S.D. (mg/m³)	0.354	2.121	0.001	BDL(DL:0.0001)
Range (LL – HL) mg/m3	2.49 – 3.2	14.37 – 18.62	0.003 – 0.004	BDL(DL:0.0001)

	General information		
Type of data	Gas analysis		
Place of experimentation	Material Engineering Department (SPECIFIC), Swansea University Prifysgol Abertawe		
Dates of the experiments	2018 - 2020		
	<u>Feedstock</u>		
Type of faecal material	Faecal sludge from anaerobic baffled reaction from a decentralised wastewater treatment system		
Location of collection	Durban, South Africa		
Age before collection	Unknown		
Moisture content	~ 85%wt		
Total solids content	~ 15%wt		
Volatile solids content	Not measured		
Ash content	Not measured		
Presence of trash?	Yes (mainly small pieces of paper after pre-screening during pit emptying)		
Pre-treatment	Screening to remove trash		
	Experimental Procedure		
Drying experimental setup	Thermogravimetric analyser - simultaneous thermal analysis Perkin Elmer STA 6000		
Holding or residence time	~ 40 - 80 min		
Operating conditions	 Set temperature: 55 and 155°C Heating rate: 10°C/min Carrier gas: nitrogen Flow rate: 30 mL/min 		
Sample form in the dryer	~ 40 mg in a crucible		
Analysed parameters	Identification of chemical compounds in the gas stream		
Employed method	Use of the Fourier transform infrared (FTIR) spectroscopy analyser Perkin Elmer Spectrum 100		
	<u>Publications</u>		
-			


_

Additional Notes


- o Samples couriered from South Africa
- o FTIR analyser hyphenated to the STA
- No quantification of the concentration of the identified compounds
- Considerable drying of the sample before reaching the set temperature at 155°C

Description of Data

FTIR spectrum during drying up to 55°C at different times of analysis



FTIR spectrum during drying up to 155°C at different times of analysis



- Main regions identified:
 4000 3400 cm⁻¹ → H₂O
 (O-H stretch)
 2400 2250 cm⁻¹ → CO₂
 1800 650 cm⁻¹ → possible organic compounds (ether, ester, alcohol, aromatic, amine, alkene) and H₂O scissoring
- Gas from drying composed by water (as expected), carbon dioxide and organic compounds

General information			
Type of data	Gas analysis		
Place of experimentation	Material Engineering Department (SPECIFIC), Swansea University Prifysgol Abertawe		
Dates of the experiments	2018 - 2020		
	<u>Feedstock</u>		
Type of faecal material	Faecal sludge from urine diversion dry toilets		
Location of collection	Durban, South Africa		
Age before collection	1 – 3 years		
Moisture content	~ 70%wt		
Total solids content	~ 30%wt		
Volatile solids content	Not measured		
Ash content	Not measured		
Presence of trash?	Yes (mainly stones, hair and plastics)		
Pre-treatment	Screening to remove the trash		
	Experimental Procedure		
Drying experimental setup	Thermogravimetric analyser - simultaneous thermal analysis <i>Perkin Elmer STA 6000</i>		
Holding or residence time	~ 40 - 80 min		
Operating conditions	 Set temperature: 55 and 155°C Heating rate: 10°C/min Carrier gas: nitrogen Flow rate: 30 mL/min 		
Sample form in the dryer	~ 40 mg in a crucible		
Analysed parameters	Identification of chemical compounds in the gas stream		
Employed method	Use of the Fourier transform infrared (FTIR) spectroscopy analyser Perkin Elmer Spectrum 100		
	<u>Publications</u>		
-			


_

Additional Notes


- o Samples couriered from South Africa
- o FTIR analyser hyphenated to the STA
- o No quantification of the concentration of the identified compounds
- Considerable drying of the sample before reaching the set temperature at 155°C

Description of Data

FTIR spectrum during drying up to 55°C at different times of analysis



FTIR spectrum during drying up to 155°C at different times of analysis



- Main regions identified: $4000 - 3400 \text{ cm}^{-1} \rightarrow \text{H}_2\text{O} \text{ (O-H stretch)}$ $2400 - 2250 \text{ cm}^{-1} \rightarrow \text{CO}_2$ $1800 - 650 \text{ cm}^{-1} \rightarrow \text{possible}$ organic compounds (ether, ester, alcohol, aromatic, amine, alkene) and H_2O scissoring
- Gas from drying composed by water (as expected), carbon dioxide and organic compounds

	General information		
Type of data	Gas analysis		
Place of experimentation	Materials Engineering Department (SPECIFIC), Swansea University Prifysgol Abertawe		
Dates of the experiments	2018 - 2020		
	<u>Feedstock</u>		
Type of faecal material	Faecal sludge from urine diversion dry toilets		
Location of collection	Durban, South Africa		
Age before collection	1 – 3 years		
Moisture content	~ 95%wt		
Total solids content	~ 5%wt		
Volatile solids content	Not measured		
Ash content	Not measured		
Presence of trash?	Yes (mainly stones, hair and plastics)		
Pre-treatment	Screening to remove the trash		
	Experimental Procedure		
Drying experimental setup	Thermogravimetric analyser - simultaneous thermal analysis Perkin Elmer STA 6000		
Holding or residence time	~ 40 - 80 min		
Operating conditions	 Set temperature: 55 and 155°C (during 80 and 40 minutes respectively) Heating rate: 10°C/min Carrier gas: nitrogen Flow rate: 30 mL/min 		
Sample form in the dryer	~ 40 mg in a crucible		
Analysed parameters	Identification of chemical compounds in the gas stream		
Employed method	Use of the Fourier transform infrared (FTIR) spectroscopy analyser Perkin Elmer Spectrum 100		
	<u>Publications</u>		
-			


-

Additional Notes

- Samples couriered from South Africa
- FTIR analyser hyphenated to the STA
- o No quantification of the concentration of the identified compounds
- o Considerable drying of the sample before reaching the set temperature at 155°C

Description of Data

FTIR spectrum during drying up to 55°C at different times of analysis



- Main regions identified:


 4000 3400 cm⁻¹ → H₂O

 (O-H stretch)

 2400 2250 cm⁻¹ → CO₂

 1800 650 cm⁻¹ → possible organic compounds (ether, ester, alcohol, aromatic, amine, alkene) and H₂O scissoring
- Gas from drying composed by water (as expected), carbon dioxide and organic compounds

FTIR spectrum during drying up to 155°C at different times of analysis



	General information		
Type of data	Gas analysis		
Place of experimentation	Material Engineering Department (SPECIFIC), Swansea University Prifysgol Abertawe		
Dates of the experiments	2018 - 2020		
	<u>Feedstock</u>		
Type of faecal material	Human faeces		
Location of collection	Cranfield, UK		
Age before collection	Fresh		
Moisture content	~ 60%wt		
Total solids content	~ 40%wt		
Volatile solids content	Not measured		
Ash content	Not measured		
Presence of trash?	No		
Pre-treatment	Mixing		
	Experimental Procedure		
Drying experimental setup	Thermogravimetric analyser - simultaneous thermal analysis Perkin Elmer STA 6000		
Holding or residence time	~ 40 - 80 min		
Operating conditions	 Set temperature: 55 and 155°C Heating rate: 10°C/min Carrier gas: nitrogen Flow rate: 30 mL/min 		
Sample form in the dryer	~ 40 mg in a crucible		
Analysed parameters	Identification of chemical compounds in the gas stream		
Employed method	Use of the Fourier transform infrared (FTIR) spectroscopy analyse Perkin Elmer Spectrum 100		


_

Additional Notes


- o Fresh faeces collected from voluntary and anonymous donations
- o FTIR analyzer hyphenated to the STA
- No quantification of the concentration of the identified compounds
- Considerable drying of the sample before reaching the set temperature at 155°C

Description of Data

FTIR spectrum during drying up to 55°C at different times of analysis



FTIR spectrum during drying up to 155°C at different times of analysis



- o Main regions identified: $4000 - 3400 \text{ cm}^{-1} \rightarrow \text{H}_2\text{O}$ (O-H stretch) $2400 - 2250 \text{ cm}^{-1} \rightarrow \text{CO}_2$ $1800 - 650 \text{ cm}^{-1} \rightarrow$ possible organic compounds (ether, ester, alcohol, aromatic, amine, alkene) and H₂O scissoring
- Gas from drying composed by water (as expected), carbon dioxide and organic compounds